


## Roman Blind Box-Bay Measuring Guide

Roman blinds are a perfect choice for box-bay windows, as the material hides the mechanics of the blind you're left seeing only the fabric you chose. By following this guide, the blinds will almost meet in the corners without overlap, meaning all three blinds operate smoothly.

### Measuring



When measuring, first of all take the measurements directly into the corners of the bay for both the front and the side blinds. For the width of the blind for the front, reduce the corner to corner measurement by 90mm, this will allow for the 45mm space that is required either side. For the widths of the side blinds, reduce the corner to corner measurement by 45mm. Finally, order all three of your blinds as 'exact fitting'.

### Drop

This is the same for all three blinds, even if you find that one window is longer than the others. This will ensure that when the roman blinds are lowered, they will all sit level. The measurement will be from the point where the blind is being mounted down to the window sill. Remember that you will need a flat space of at least 30mm to mount the brackets securely. Measure the drop for all three windows and use the smallest of the three.

### Important!

Always check the widths in three places as you would for a regular recessed windows. Bay windows are prone to movement and you may find that the widths vary even if at first glance the windows look square. It is always the smallest of three measurements that you should be using.